

# Fisher Gold Bug 2 Metal Detector



## Controls:

THRESHOLD: Small shaft on rear of control housing, controls threshold tone. •

MODE: Three-position toggle switch:

1. IRON DISC Mode for iron discrimination.
2. NORMAL Mode for normal All Metal operation.
3. AUDIO BOOST Mode for hearing faint, deep targets.

• BATTERY TEST/SENSITIVITY: Dual-purpose potentiometer with switch for Audio-Tone battery test, controls sensitivity to targets, electrical interference and ground minerals.

• GROUND REJECT: Dual-knob control used to electronically tune the electronics to ignore ground minerals. A small, single-turn coarse adjust knob is stacked on a large, 16-turn fine tuning control.

• VOLUME: Turns the power on and controls signal response volume.

• HEADPHONES: Jack for most mono and stereo headphones with 1/4-inch plug.

## Features:

- Powerful 71kHz Operation for extreme sensitivity to small gold nuggets
- IRON DISC Mode rejects iron (trash) targets and hot rocks
- Resistant to dust and moisture
- Boosts audio signal of small and deep targets
- Convertible to hip-mount or chest-mount
- Weighs only 2.9 lbs.
- Quartz-crystal locked electronics
- Uses two drop-in, 9 V batteries

- Dual-knob ground control for coarse and fine adjustment

UPC 089723999624

[Fisher Gold Bug 2 Metal Detector Manual](#)